


FITTING INSTRUCTIONS

REMOTE FILTER HEADS

THINK
AUTOMOTIVE
ltd

RFH1A
RFH1C
RFH1E
RFH1EM18
RFH2E
RFH2G

Oil flow from engine




Oil flow to cooler



Oil flow to cooler




Oil flow from engine



RFH3A

Oil flow to cooler



Oil flow from engine



RFH1B
RFH1D
RFH1F